



Firmware Update Guide

Xbox ONE to PS4 Super Converter



This document describes how to update the firmware of Brook Super Converter.

NOTE The update must be done on a PC; it cannot be done on a console.

NOTE Operate it on desktop PC. For laptop, please connect your laptop to power supply.

NOTE Do it on Windows 7(and above) or Mac.

NOTE No need to install USB Driver for the firmware update.

NOTE Don't connect your controller/stick when doing update

NOTE It may take some time for the firmware to run in different PC/system.


NOTE Disable antivirus when operating.

NOTE If there's any problem during update, please try to

1. Disconnect, reconnect and retry
2. Switch another USB port and retry
3. Use another PC and retry
4. Restart PC and retry
5. Restart firmware and retry
6. Make sure you download the correct file
7. If you have installed ZeroPlus Driver before, remove it and retry

STEP 1 Download the latest update file from Brook's website:

<http://www.brookaccessory.com/download/>



STEP 2 There are two versions,

Normal Version



XBOXONEtoPS4_V22_201609



TE Version

XBOXONEtoPS4_TE_V22_201609

STEP 3 Choose the version you want and run it.



STEP 4 Plug converter into USB port on PC

Normal Mode: Blue LED


TE Mode: Purple LED

✘Note: Don't use USB hub when plugging into PC



STEP 5 Tick "Controller Compatibility Update" and click "START" button.



STEP 6 DO NOT remove the converter while updating**STEP 7** Update complete, click "FINISH" to close.**Normal Mode:** Blue LED**TE Mode:** Purple LED